



FORTIFIED Asphalt Shingle Re-Roof Requirements

INFO@FORTIFIEDPRO.COM
(251) 386-2230 | (504) 289-1367

MATERIAL PHOTOS

- 1 - Label on .113, 2 3/8" Ring Shank Nails Box
- 1 - Underlayment Label
- 1 - Roof Deck Tape Packaging (when applicable)
- 1 - Roof Vent Packaging
- 1 - Low Slope Roofing Material Packaging
- 1 - Backside of Shingle Package/Wind Label
- 1 - Self Adhered Starter Strip Packaging

We will also accept invoices showing delivery to site address for material photos.

RE-ROOF PROCESS PHOTOS

- 4 - Roof Deck Nailing with **measuring tape 4" and 2 3/8" ring shank nails**

12d 3" Ring Shank required when over decking

- 4 - Installed Underlayment
- 4 - Roof Deck Tape (when applicable)
- 4 - Showing Underlayment Fastener Spacing with Measuring Tape
- 4 - 4" Drip Edge Nail Pattern

Drip edge always goes on top of the underlayment

- 4 - Installed Starter Strips
- 4 - Showing all 4 Elevations of Final Installed Roof Cover
- 1 - Showing all Installed Roof Vents
- 1 - For Each Gable Showing Removable Cover Installed/Permanently Closed
- 4 - Installed Low Slope Products